

## دستورالعمل نرم افزار ارتقاء

این دستورالعمل نحوه ارتقاء فریم ور برخی محصولات هارمن/کاردن و جی بی ال را توضیح میدهد.

ابتدا، دستگاهی را که قصد ارتقاء آن را دارید به کامپیوتری که کابل USB هم دارد وصل کنید. دقت کنید که بعضی کابلها ممکن است فقط برای شارژ باشند و برای ارتقاء کار نکنند. چنین کابلی را ممکن است در جعبه دستگاه خودتان بیابید. کامپیوتر باید ویندوز داشته باشد و به اینترنت هم وصل باشد.

فایل زیپ شده برنامه را که دانلود کرده اید روی کامپیوتر دارای ویندوز کپی کنید و آن را از حالت زیپ شده خارج کنید. روی فایل "Harman Update" کلیک کنید تا اجرا شود.

حالا صفحه خوش آمدگویی باز میشود .

# Welcome

Harman upgrade software

## END USER SOFTWARE LICENSE AGREEMENT

**IMPORTANT-READ CAREFULLY:** This software is intended for receipt, installation and use only by end-user customers who are adults (over the age of 18 in most jurisdictions) and who own the Harman product appropriate for the software. Prior to continuing, you must agree to the following End-User License Agreement ("Agreement") as indicated by pressing the "CONTINUE/ I ACCEPT" button at the end of this page. If you do not agree to the terms of this Agreement, press the "EXIT/ I DO NOT ACCEPT" button at the end of this page to reject the Agreement and to cancel receipt and/or installation of the software. This Agreement is binding between you and Harman International Industries, Incorporated ("Harman") for the software, services and supporting material, if any, that accompanies this Agreement.

**1. BACKGROUND.**

1.1 Customer desires to receive the Software for the sole purpose of the Software's installation, and use in the operation and/or maintenance of a Harman product.

1.2 Harman desires to provide such Software to Customer for use exclusively in connection with a Harman product. Such use shall be at Customer's sole risk.

Customer and Harman further agree as follows:

EXIT / I DO NOT ACCEPT

CONTINUE / I ACCEPT

سپس روی دکمه CONTINUE / I ACCEPT کلیک کنید. حالا برندهای زیر نمایش داده میشوند:

Welcome


Select the brand of your product

JBL

AKG

harman/kardon

Infinity


 Harman upgrade software V1.9.0 All rights reserved.

روی برند دستگاهتان کلیک کنید . صفحه بعدی نوع محصول را باز خواهد کرد. اگر مثلاً برند **JBL** را انتخاب کرده باشید صفحه ای شبیه به شکل زیر ظاهر خواهد شد:


← Brand

JBL


×




Portable




Home



Headphone




Car Audio

 Harman upgrade software V1.9.0 All rights reserved.

روی نوع محصول دستگاهتان کلیک کنید.

سیستم شروع به ارتباط با سرور ارتقاء در اینترنت میکند تا دنبال فایل‌های ارتقاء بگردد. یک نوار پیشرفت این امر را نشان میدهد.

وقتی سرور پیدا شد، فایل‌های ارتقاء محصولی که انتخاب کرده بودید نشان داده خواهند شد. صفحه ای شبیه به شکل زیر:



روی مدلی که میخواهید کلیک کنید و دستورات روی صفحه را دنبال کنید. ممکن است لازم شود که دستگاهتان را روشن کنید یا ترکیبی از دکمه‌ها را فشار دهید. اگر ارتقاء جدیدی در دسترس نباشد یا قبلاً خودتان آن را ارتقاء داده باشید، به شما اطلاع داده میشود.

تأیید کنید که میخواهید ارتقاء بدهید. زمان تقریبی ارتقاء نشان داده خواهد شد. وقتی ارتقاء دستگاهتان تمام شد، میتوانید آن را جدا کنید.

## تهیه شده در بخش خدمات پس از فروش شرکت شاب

آدرس: تهران، چیدر، میدان ندا، پلاک ۵۸

تلفن: (۱۰ خط) ۲۲۶۸۶۸۱۸

[www.shobtech.com](http://www.shobtech.com)  
[technical@shobtech.com](mailto:technical@shobtech.com)

