



USER MANUAL ►

Mifa

LISTEN.MIFA THE MUSIC POWER TO YOUR DEEP HEART!



01 Warnings

English

- ◆Please use and store this product at room temperature
- ◆Do not expose this product to rain or wet conditions
- ◆Do not throw and drop this product to avoid product damage
- ◆Do not self-dismantling ,repair and transform the product
- ◆Do not use chemical solvent cleaning the product
- ◆Please don't arbitrarily discarded or placed the lithium battery in the fire in order to avoid the risk of explosion

02 Product Features


©DSP 3D surround stereo sound effect

- ©3D mega bass enhance
- © Support Bluetooth wireless connection and with hands-free function
- © Support Bluetooth one button reconnect
- ©Support APE,FLAC format audio files
- © Support MP3, WAV, WMA format audio files
- O Auxiliary enabled , data exchanging directly enabled
- ©Intelligent power save , with LED charging indicator
- OAutomatically power off when there is no any operation in 10 minutes
- If there is no operation in 20 minutes , It will power off automatically while in bluetooth mode.
- ©With voice prompt function
- © Support ring tone play under iOS system

English


03 Packing Content

English



04 Keys Function


English



Mode : Press this key to exchange the functions among Bluetooth mode/ Micro SD mode/ Auxiliary input


05 Interface function

English



06 Charging LED light

English



[–] Battery Indicator	Charging LED light
Continuous white	کرد کرد کرد 75% of full charge
Continuous white	Continuous Flashing white Continuous Flashing Continuous Flashing
Continuous white	Continuous Flashing in turn white $2 = 2 = 2 = 2$
> 0 0 15% of full charge Turn to be red (low battery ,charge needed)	Flashing in turn
Flashing red	




Notes:

When low battery , power on the red LED fast flickering , and then power off 15 seconds later

07 MODEL LED Indicator

English



- Power on : white flashing , ready for bluetooth paring , paired continuous white
- Pause in bluetooth mode: white slow flashing
- Micro SD card playing mode : white LED light keeps on

 Image: SD card playing pause : White LED light flickering

 Image: SD card playing pause : White LED light keeps on

 Image: SD card playing pause : White LED light keeps on

 Image: SD card playing pause : White LED light keeps on

 Image: SD card playing pause : White LED light keeps on

 Image: SD card playing pause : White LED light flickering


 Image: SD card playing pause : White LED light flickering

 Image: SD card playing pause : White LED light flickering

 Image: SD card playing pause : White LED light flickering

 Image: SD card playing pause : White LED light flickering

Normal status : Press and hold this key to open or close locking key function , white flashing one time to indicate



Notes:



- 1, The default password is "0000"
- 2. The speaker will auto connect the last paired device when it powers on
- 3. If want to connect other devices , press 🖉 to disconnect first ,and then the speaker

Is discoverable and ready to pair a new device

09 Technique Parameters

English

Basic parameters		
Speaker type	Portable Bluetooth Speaker	
Speaker system	2.0 channel +bass	
Active /passive	Active	
Operate mode	Button	
Main functions	DSP 3D surround stereo sound effect, Bluetooth ,hands-free , Auxiliary etc	
Storage type	Max.32GB micro SD card	
Power supply	built in 1200mAh lithium battery	
	DC5V-500mA USB adapter	
Technique Parameters		
Loudspeaker	1.5inch *2 +bass radiator	
RMS	6WTHD=10%	
Frequency Response	100Hz~20KHz	
Bluetooth version	Bluetooth 3.0+EDR	
USB specification	USB2.0 Compatible with USB1.1	
Playing function		
File format	APE、FLAC、WAV、WMA、MP3	
Bit Rate	MP3、8Kbps-320Kbps	
	WMA、32Kbps-384Kbps	
	APE、600Kbps-1400Kbps	
	FLAC、600Kbps-1400Kbps	
	WAV、32Kbps-1200Kbps	



Product size:W55xD55xH148mm Product weight: 300g (including battery inside)

10 FAQ

English

Problems	What to do
Paired Bluetooth device will not connect	1.Restart the speaker
	2.If need password , please input "0000"
Music play hang up	Please check the Bluetooth connection valid distance or if something cut off the signal
File format fault -	1. Check if the TF card format is right (the speaker just can support FAT 32 format TF card)
	2.Check if the music file format store in TF card is right ,the speaker just can support APE/FLAC/WAV/WMA/MP3 format files
Speaker indicates a connection .but is not	
playing music	2.Check if the speaker is in mute or pause
Poor sound quality From the AUX source	Check if the audio cable connect right
Speaker will not turn on	Check if the battery is low
System halted	Reset the speaker

MIFA INNOVATIONS LLC Hotline : 4007-881-899 www.mifalife.net Made in China

©2013 MIFA all rights reserved .The product and the packaging trademarks or registered trademarks of MIFA INNOVATIONS LLC in the united states or other countries .All rights reserved . Other trademarks and trade names are registered mark of their respective owners . MIFA INNOVATIONS LLC for any errors that may occur in this manual does not undertake any responsibility. The information contained in this manual are subject to change no prior notice.