规格 74x84mm   128克铜版纸   折页

Mifa

X17
Wireless Earbuds

Table of Contents

---

01 Warnings
English

◆To ensure proper use and trouble-free operation, please carefully read this user manual first.
◆Please use and store the product at room temperature.
◆Do not throw and drop the product to avoid damages.
◆Do not disassemble the product, or make any modifications to the structure or any part of it.
◆Please charge with a rated voltage charger.
◆Keep the product out of children's reach.

◆Do not replace the built-in batteries of earphones and charging box.
◆Do not expose the product to fire, high temperature, direct sunlight, etc.

---

02 Packing list
English

Charging Box

Earphones

USB Type-C Charging Cable

User Manual

---

03 Charging Box
English

Plug the USB charging cable into the USB type-C charging port to charge the box. Or put the box upright on a wireless charger to charge.

Digital Display

USB Type-C Port

Battery indicators of charging box:
The display will show the reminding power of box when you open or close the cover. The number will flash when charging, the screen will show "100" when fully charged and will turn off about 60 seconds later.

Battery indicator of earphones:
Put the earphones back into the box to charging the earphones. The battery icons will flash when charging, will turn off after fully charged.

Features with NTC temperaturecontrol protection, X17 headphones will not charge if the temperature reaches 45 degrees or higher. (Charging case will automatically protect themselves in that case.) It is recommended to stop charging (or disconnect wireless charging) firstly, recharge after the temperature drops below 45 degrees.

---

04 Power on/ Power off
English

Power on and Pair Automatically
Open the box, the earphones will power on with red light staying on for one second, then pair with each other automatically. After pairing, the blue lights flicker quickly which means they are waiting for pairing with a smart phone.

LED Indicator

Power off
Put the earphones into the charging box and close the box, they will power off automatically and start to be charged.

Function Button

Manually power on: Press and hold the button for 2 seconds to turn on the earbuds. The red indicator will stay on for 1 second with a prompt sound.
Manually power off: Press and hold the button for 5 seconds to turn off the earbuds. The red indicator will stay on for 2 seconds with a prompt sound.

---

05 Bluetooth Connection
English

Binaural Mode
After the earbuds connect with each other successfully, the blue lights of them will quickly flash, activate the Bluetooth of your device and search for "Mifa X17". Select it on the list to connect.

Single Mode
Take out one earbud, it will turn on and the blue light will flash quickly, activate the Bluetooth of your device and search for "Mifa X17". Select it on the list to connect.

Other instructions
1. The earbuds will re-connect the last paired smart phone automatically once they power on.
2. If you want to connect them with another device, please turn off the Bluetooth of the last paired device and then the earbuds will be available for pairing with a new device.
3. Put the earbuds back in the charging box and they will charge automatically.
4. The earbuds will power off automatically in 5 minutes if they do not connect to any Bluetooth devices.

---

06 Button Operation
English

After connecting with your smart device, you can operate the earbuds as below.

Function Button

Hands-free calls
Press the button of any earbud to answer the coming call and press again to hang up.
Reject phone calls
Press and hold the power button of any earbud for 2 seconds to reject a call.

Music playback controls
Press the button of any earbud once to play/ pause.
Press the button three times of any earbud to play the previous track.
Press the button twice of any earbud to play the next track.

Siri voice mode: Press and hold the button of any earbud for 2 seconds to activate or turn off Siri voice mode.

Remove paired devices
Take out one earbud, make sure it is not paired with any device, press the button twice and then press and hold the button until the blue light quickly flash three times and then red light stay on for 2 seconds. Then take out another earbud and do the same operation to it to remove paired devices.

---

07 Product Specifications
English

Product Appearance

Weight of Charging box: 35.3g	Weight of Each Earbud: 3.5g
Size of Charging box: 49*49*25mm	Size of Earbud: 17.7*18.1*40.3mm

Sound

Loudspeaker: 1pc ♦ 10mm full-range speaker	Acoustic Structure: Half in ear
Loudspeaker Frequency: 20Hz - 20KHz	Resistance: 32 Ω ±15 %
Max Output: 10mW	

Bluetooth

Bluetooth Version: Bluetooth 5.0	Bluetooth Frequency: 2.4 - 2.48GHZ
Bluetooth Working Range: ≥ 0M	Bluetooth Protocol: HSP/ HFP/ A2DP/ AVRCP
Supported BT Format: SBC, AAC	Sensitivity: ≤ 8dBm
S/N: > 90dB	

Microphone

Omnidirectional Clear Microphone	Sensitivity: -42± 1dB

Battery

Battery of each Earbud: 40mAh	Battery of Charging box: 400mAh
Charging Time of Earbuds: about 1.1 hour	Charging Time of Box: about 2 hours

---

08 注意事项
简体中文

● 请在常温环境中存放以及使用本产品；
● 请勿将本产品长期暴露在雨中或潮湿环境中；
● 请勿丢弃，避免因跌落造成产品损坏；
● 请勿自行拆解，修理和改造本产品；
● 请使用额定电压的充电器充电本产品；
● 请将产品放置在儿童接触不到的地方。

● 请勿更换耳机内的电池与充电仓的不可更换电池
● 不得暴露在诸如日照、火烤或类似过热环境中

JUST ENJOY

---

09 产品标配
简体中文

使用USB Type-C充电线为充电盒充电，或将充电盒顶面朝上放置在兼容的无线充电器上。

数码管显示屏

USB Type-C接口

充电仓

耳机

USB Type-C
充电线

使用手册

---

10 产品充电
简体中文

使用USB Type-C充电线为充电盒充电，或将充电盒顶面朝上放置在兼容的无线充电器上。

数码管显示屏

USB Type-C接口

充电仓电量指示：
开关盖显示充电仓剩余电量，充电时屏显个位数闪烁，屏显"100"即充满，约60秒后熄灭。

左右耳机充电柱指示：
将左右耳机放回充电仓，关闭上盖左右充电柱自动亮闪烁进入充电状态，充满后熄灭。

提示：内置NTC温控保护功能，当充电盒温度达到45度或以上，充电盒会自动安全保护无法充电；待温度下降到45度以下，才可以恢复充电。建议此时断开无线充或充电线，待温度降低后再充。

充电仓

耳机

USB Type-C
充电线

使用手册

---

11 开关机
简体中文

开机：
打开充电仓上盖，指示红灯长亮1秒开机，即自动进入TWS配对，稍后左右耳机红灯长亮1秒后，指示蓝灯快闪提示，等待手机连接配对。

内置LED指示灯

关机：耳机放入充电仓，关闭上盖自动关机并充电。

耳机功能键

手动开机：长按耳机功能键约2秒，指示灯红灯亮约1秒开机，并伴有提示音。

手动关机：长按耳机功能键约5秒，指示灯红灯长亮约2秒关机，并伴有提示音。

---

12 连接设备
简体中文

双耳使用：
左右耳机开机互联配对后，左右耳机指示蓝灯快闪提示，等待手机连接配对时，在手机蓝牙设备列表中找到"Mifa X17"，点击后即可连接成功。

单耳使用：
单只耳机开机后，指示灯蓝灯呼吸闪烁，等待手机连接配对。在手机蓝牙设备列表中找到"Mifa X17"，点击后即可连接成功。

其它：
1. 蓝牙耳机开机后，会自动连接最近一次配对过的手机。
2. 如需配对其它手机，请关闭原手机蓝牙，在蓝牙耳机开机状态下，其它手机打开蓝牙即可搜索到"Mifa X17"。
3. 不使用耳机时，请将耳机放入充电仓内，耳机将会自动关机并补充电量。
4. 如果开机后蓝牙一直未连接，大约5分钟后耳机将自动关机。

---

13 按键操作
简体中文

耳机与手机蓝牙连接后可进行以下操作

耳机功能键

耳机通话
短按任一耳机功能键，接通电话，再次短按挂断。
拒接通话
长按任一耳机功能键约2秒拒接电话。

音乐播放控制
短按任一耳机功能键，播放/暂停
短按任一耳机功能键3下 切换上一曲
短按任一耳机功能键2下 切换下一曲
Siri语音助手模式
蓝牙连接手机，非通话状态，长按左/右耳机功能键约2秒后可手动激活/退出Siri

清空配对记录
耳机开机状态，当未与TWS配对，也未连接蓝牙，依次操作左右耳机，短按功能键3次，第3次长按不松手，直至耳机蓝灯快闪3下后，红灯长亮约2秒关机。

---

14 产品参数
简体中文

外观

电池仓重量：35.3g	单只耳机重量：3.5g
电池仓尺寸：49*49*25mm	单只耳机尺寸：17.7*18.1*40.3mm

声音

发声单元：10 mm铝圈全频发声单元	声学结构：半入耳式
喇叭频响：20Hz~ 20KHz	抗阻：32 Ω ±15 %
最大输出：10mW	

连接

蓝牙版本：5.0	蓝牙频率：2.4-2.48GHZ
蓝牙有效距离：≥10M	支持协议：HSP/HFP/A2DP/AVRCP
支持音频解码：SBC/AAC	蓝牙接收灵敏度：≤-80dBm
音频信噪比：>90dB	

麦克风

全指向高清晰麦克风	咪头灵敏度：-42±1db

电池

单只耳机电池：40mAh	充电仓电池容量：400mAh
耳机充满电时间约1.1小时	充电仓充满电时间：DC 5V-1A 约2小时