规格 74x84mm　128克铜版纸　折页

MiFa

X181
Wireless Earbuds

Table of Contents

01 - 08　English

09 - 16　简体中文

◆Do not replace the built-in batteries of earphones and charging box.
◆Do not expose the product to fire, high temperature, direct sunlight, etc.

01 Warnings　English

◆To ensure proper use and trouble-free operation, please carefully read this user manual first.
◆Please use and store the product at room temperature.
◆Do not throw and drop the product to avoid damages.
◆Do not disassemble the product, or make any modifications to the structure or any part of it.
◆Please charge with a rated voltage charger.
◆Keep the product out of children's reach.

02 Packing list　English

03 Charging Box　English

Plug the USB charging cable into the USB type-C charging port to charge the box.



Power indicators of box: The lights will stay on for 5 seconds when open the cover.

25%	the first light stays on
50%	the first and the second light stay on
75%	the first, second and the third light stay on
100%	all four lights stay on

Tip: Please charge the box when the first light flashes.

Charging indicators of box

0%~25%	the first light flashes
26%~50%	the second light flashes
51%~75%	the third light flashes
76%~100%	the fourth light flashes

All lights will stay on after fully charged.

04 Charging Earphones　English

To charge the earphones, please put them in the box and close the cover.
Tip: The charging box will not charge the earphones when it is in the low power status and all lights will turn off. Please charge the box immediately.



Earphones Charging Indicators
Put the earphones in the box and close the cover, the right and left corresponding lights stays on when charging and turn off after fully charged.

Earphones Charging Indicators
The red light stays on when charging and turn off after fully charged.

05 Power on/ Power off　English

Power on
Open the box, the earphones will power on with blue light stay on for one second. The blue light will flash quickly in the first time pairing. And then they pair with each other automatically. After they paired, the lights will flash red and blue which means they are waiting for pairing with a smart phone.

Power off
Put the earbuds into the charging box and close the box, they will power off automatically and start to be charged.



Manually power on: Press and hold the touch sensor area of any earbud about 2 seconds to turn on the earbuds. The blue indicator will stay on for 1 second with a prompt sound.
Manually power off: Press and hold the touch sensor area of any earbud about 5 seconds to turn off the earbuds. The red indicator will stay on for 2 seconds with a prompt sound.

06 Bluetooth Connection　English

Binaural Mode
After the earbuds connect with each other successfully, their lights will flash red and blue which means they are waiting for pairing with a smart phone. Activate the Bluetooth of your device and search for "Mifa X181". Select it on the list to connect.

Single Mode
Take out either of earphones, it will turn on and the light will flashes red and blue; activate the Bluetooth of your device and search for "Mifa X181". Select it on the list to connect.

Other Instructions
1. The earbuds will re-connect the last paired smart phone automatically once they power on.
2. If you want to connect them with another device, please turn off the Bluetooth of the last paired device and then the earbud will be available for pairing with a new device.
3. Put the earbuds back in the charging box and they will charge automatically.
4. The earbuds will power off automatically in 5 minutes if they do not connect to any Bluetooth devices.

07 Touch Control　English

After connecting with your smart device, you can operate the earbuds as below.

Hands-free calls: Touch the sensor area of any earbud once to answer the coming call; touch and hold the sensor area of any earbud 2 seconds to hang up.
Reject phone calls: Touch and hold the sensor area of any earbud 2 seconds to reject a call.

Music playback controls
Touch the sensor area of right earbud twice to play/ pause.
Touch the sensor area of left earbud three times to play the previous track.
Touch the sensor area of right earbud three times to play the next track.

Gaming mode: Touch the sensor area of any earbud four times to enter the gaming mode, touch four times again to exit gaming mode.

Siri voice mode: Touch the sensor area of left earbud twice to activate or exit Siri voice mode.

Remove paired devices: Put the two earphones in the box, press and hold the button of box for 3 seconds to clear the paired devices. The lights of box will quickly flash for 3 seconds if successfully.

Manually pair earphones: Put the two earphones in the box, press and hold the button of box for 10 seconds to force them pair with each other. The lights of box will flash from left to right 3 times.

08 Product Specifications　English

Product Appearance

Weight of charging box: 36g　Weight of each earbud: 6.3g
Size of charging box: 58*46.5*28mm　Size of earbud: 35.7*16*21mm

Sound

Loudspeaker: 1pc ϕ10mm full-range speaker　Acoustic structure: In Ear
Loudspeaker frequency: 20Hz - 20KHz　Resistance: 32Ω±15 %
Max output: 10mW

Bluetooth

Bluetooth version: Bluetooth 5.0　Bluetooth frequency: 2.4 - 2.48GHZ
Bluetooth working range: ≥ 10M　Bluetooth protocol: HSP/ HFP/ A2DP/ AVRCP
Supported BT format: SBC, AAC　Sensitivity: ≤ -82dBm
S/N: ≥ 90dB

Microphone

Omnidirectional clear microphone　Sensitivity: -42±1dB

Battery

Battery of each earbud: 40mAh　Battery of charging box: 500mAh
Charging time of earbuds: 1.2 hours　Charging time of charging box: about 2 hours

JUST ENJOY

mifa

MIFA INNOVATIONS LLC
Hotline：4007-881-899
www.mifa.net　Designed in US
Made in China

Copyright © MIFA. All rights reserved. MIFA, the MIFA logo and other MIFA marks are all owned and registered by MIFA INNOVATIONS LLC. All other trademarks are the property of their respective owners. The information contained here is subject to change without prior notice.

EC REP　Lidio Consulting GmbH
Geschwister-Scholl-Str. 71 60488 Frankfurt am Main, Germany
lidioconsulting@hotmail.com

UK REP　SMART INTL BUSINESS LTD
7 Pantygragwen Road, Pontypridd, Rhondda Cynon Taf, CF37 4LW, UK
jennwebb@outlook.com

09 注意事项　简体中文

- 请在常温环境中存放以及使用本产品；
- 请勿将本产品长期暴露在雨中或潮湿环境中；
- 请勿丢纸，避免因热落造成产品损坏；
- 请勿自行拆解，修理和改造本产品；
- 请使用额定电压的电源充电器充电；
- 蓝白灯即将使保修失效。

- 充电座及耳机内的电池为不可更换电池
- 不得暴露在诸如日照、火烤或类似过热环境中

10 产品标配　简体中文

11 充电盒充电　简体中文

将USB充电线插入充电盒USB Type-C接口充电。



充电盒电量指示: 打开充电盒上盖，电量指示灯常亮5秒

电量25%时	第1个灯亮
电量50%时	第1, 2个灯同时亮
电量75%时	第1, 2, 3个灯同时亮
电量100%时	4个灯同时亮

提示：第一个灯闪烁时，代表充电盒电量不足，请及时及充电。

充电盒外接充电指示说明:

电量0%-25%	第1个灯闪烁
电量26%-50%	第2个灯闪烁
电量51%-75%	第3个灯闪烁
电量76%-100%	第4个灯闪烁

充电盒充满电后，指示灯全部点亮

12 耳机充电　简体中文

耳机放入充电盒，并关闭充电盒盖，即可为耳机充电。
提示: 充电盒低电时，会关闭耳机充电功能，进入低电保护状态，电量指示灯全不亮，此时需要给充电盒充电激活后继续使用。



耳机充电指示灯
耳机放入充电盒关闭上盖，左右对应电量指示灯点亮，充满熄灭。

耳机充电指示灯
充电时红灯长亮，充满熄灭

13 开关机　简体中文

开机:
打开充电盒上盖，指示蓝灯长亮1秒开机，即自动进入TWS配对，（首次配对指示蓝灯快闪提示），配对成功左右耳机指示灯红蓝交替闪烁，等待手机连接配对。

单耳使用:
单只耳机开机后，指示灯红蓝交替闪烁提示，等待手机连接配对，在手机蓝牙设备列表中找到"Mifa X181"，点击后即可连接成功。

关机:
开机状态将左右耳机放入充电盒，关闭上盖将自动关机进入充电状态。

手动开机: 长按左右耳机触控区域约 2 秒，指示灯蓝灯长亮约 2 秒后开机，并伴有提示音。

手动关机: 长按左右耳机触控区域约5秒，指示灯红灯长亮约 2 秒后关机，并伴有提示音。

14 连接设备　简体中文

双耳使用:
左右耳机开机互联配对后，左右耳机指示灯红蓝交替闪烁提示，等待手机连接配对，在手机蓝牙设备列表中找到"Mifa X181"，点击后即可连接成功。

其它:
1. 蓝牙耳机开机后，会自动连接最近一次配对过的手机。
2. 如需配对其它手机，请关闭原手机蓝牙，在蓝牙耳机开机状态下，其它手机打开蓝牙即可搜索到"Mifa X181"。
3. 不使用耳机时，请将耳机放入充电仓收纳盒，耳机将会自动关机并补充电量。
4. 如果开机后蓝牙一直未连接，大约5分钟后耳机将自动关机。

15 触控操作　简体中文

耳机与手机蓝牙连接后可进行以下操作

耳机通话 单击任一耳机触控区域，接通电话。长按任一耳机触控区域约2秒挂断。
拒接通话 长按任一耳机触控区域约2秒拒接电话。

音乐播放控制 双击右耳机触控区域，播放/暂停
三击左耳机触控区域　**切换上一曲**
三击右耳机触控区域　**切换下一曲**

游戏模式 四击任一耳机触控区域，开启游戏模式，再次四击关闭游戏模式

Siri语音助手模式 双击左耳机触控区域，激活或退出Siri语音识别

清空配对记录 左右耳机放入充电盒，长按充电盒按键3秒，充电盒电量指示灯同时快闪3次，即可清除手机配对信息

左右耳机强制配对
左右耳机放入充电盒，长按充电盒按键10秒，充电盒电量指示灯从左往右跑马显示3个循环。

16 产品参数　简体中文

外观

重量: 电池仓约36g	单只耳机约8.3g
尺寸: 电池仓58*46.5*28mm	单只耳机 35.7*16*21mm

声音

发声单元:10mm扬圆全频发声单元	声学结构:入耳式
喇叭频响:20Hz- 20KHz	抗阻:32 Ω ±15 %
最大输出:10mW	

连接

蓝牙版本:5.0	蓝牙频率:2.4-2.48GHZ
蓝牙有效距离:≥10M	支持协议:HSP/HFP/A2DP/AVRCP
支持音频解码:SBC/AAC	蓝牙接收灵敏度:≤-82dBm
音频信噪比:≥90dB	

麦克风

全指向高清晰麦克风	咪头灵敏度:-42±1db

电池

单只耳机电池:40mAh	充电仓电池容量:500mAh
耳机充满电时间:约1.2小时	充电仓充满电时间:DC 5V-1A 约2小时

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Any changes or modifications not expressly approved by the party responsible for compliance
could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception,
which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction
FCC ID: 2AXDX-X18